Bedienungsanleitung Guía del usuario Notice d'utilisation Manual do Proprietário





Please read and keep all safety and use instructions.

Important Safety Instructions

German warranty card provided separately.

WARNINGS/CAUTIONS

- Do NOT use the headphones with noise canceling mode at any time the inability to hear surrounding sounds may present a danger to yourself or others, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad, etc.
- Keep batteries out of reach of children.
- Please dispose of used batteries properly, following any local regulations.
- Danger of explosion if batteries are incorrectly replaced.
- Batteries may cause a fire or chemical burn if mishandled. Do not recharge, disassemble, heat, or incinerate.
- When a replacement is needed, use only a AA (LR06) alkaline batteries.

Please read and save this guide

Please read this guide carefully. Save this guide for future reference and make it easily accessible for passengers and third parties who use this headset.

Switch to an alternate communications method in the event of a headset issue.

In the unlikely event of any headset issue or failure in the passive noise reducing mode, switch to an alternate communications method and use standard cockpit resource management skills to minimize distractions.

Use the headset at a moderate volume level.

To avoid hearing damage, use the headset at a comfortable, moderate volume level. Limit the headset volume to safe levels that do not interfere with your ability to hear informational sounds and warning alarms, such as stall warnings or gear up, while piloting.

• Turn the headset off if it emits any loud noise.

As with any complex electronic device, it is possible for this headset to fail during operation. Symptoms of failure, which may include loud tones, distortion, feedback squeals and loss of communications signal in the headset, can occur in either the Acoustic Noise Cancelling[™] mode (turned on) or in the passive mode (turned off). If the headset emits any loud noise and the related loss of communications in the Acoustic Noise Cancelling[™] mode, turn off the power switch. The headset will continue to provide communications in the passive noise-reducing mode. If the problem persists, see "Troubleshooting" on page 44.

· Be aware of sound differences while wearing the headset.

With the headset's active and passive noise reduction, typical aircraft sounds (such as engines, propellers, warning alarms, and other sound sources) may not sound familiar. Make sure you can hear and recognize these sounds when using the headset while operating any aircraft.

Do NOT make phone calls while piloting.

Do not use the headset for telephone calls during flight operations.

· Make sure your aircraft communications system volume control is easily accessible.

This control affects the strength of the communications signal coming into the headset. Make sure you can understand critical communications even with Acoustic Noise Canceling mode turned off. In this case, you may need to turn up the aircraft communications system volume. In passive mode, the volume controls on the control module will automatically be set to maximum volume. For additional volume control, use the intercom or radio volume control. If your headset is aircraft powered, connect the headset to the aircraft power sources only as described in "Aircraft Connectors" on page 28".

• Make sure portable devices do not interfere with the aircraft's navigation and communication systems.

It is the pilot's responsibility to ensure that portable devices do not interfere with the aircraft's navigation and communication systems, as well as to determine if the portable device is suitable for use with the headset.

• Use only AA alkaline batteries.

To avoid risk of explosion, replace the batteries only with AA alkaline batteries. Properly dispose of used batteries.

• Do NOT repair the headset yourself.

Contact the Bose organization in your country/region for specific care, return and shipping instructions. Visit: global.Bose.com

• Do not use the headset with a helmet or as part of a crash protection system.

The headset is not intended for such use, and has not been certified for crash protection. Dismantling, reassembly or modification of the headset, or any part, for use in a helmet or other crash protection system could result in severe bodily injury and such unauthorized use will void the limited product warranty.

• Do NOT immerse the headset or any parts in water or any other liquid.

See "Clean the headset" on page 40 for cleaning instructions.



Contains small parts which may be a choking hazard. Not suitable for children under age 3.

This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.

- Do NOT expose this product to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the product.
- Do NOT make unauthorized alterations to this product.
- Do not expose products containing batteries to excessive heat (e.g. from storage in direct sunlight, fire or the like).

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by Bose Corporation could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with FCC and Industry Canada radiation exposure limits set forth for general population. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CAN ICES-3 (B)/NMB-3(B)

Bose Corporation hereby declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and all other applicable EU directive requirements. The complete declaration of conformity can be found at: www.Bose.com/compliance

Frequency band of operation 2400 to 2480 MHz:

- · Bluetooth: Maximum transmit power less than 20 dBm EIRP.
- Bluetooth Low Energy: Maximum power spectral density less than 10 dBm/MHz EIRP.



Please dispose of used batteries properly, following local regulations. Do not incinerate.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.



Na	mes and	d Contents	of Toxic or H	azardous Sub	stances or Eleme	ents
	Toxic or Hazardous Substances and Elements					
Part Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent (CR(VI))	Polybrominated Biphenyl (PBB)	Polybrominated diphenylether (PBDE)
PCBs	Х	0	0	0	0	0
Metal Parts	Х	0	0	0	0	0
Plastic Parts	0	0	0	0	0	0
Speakers	Х	0	0	0	0	0
Cables	Х	0	0	0	0	0
This table is prepared i	n accordan	ce with the pro	visions of SJ/T 113	64.		
O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.						
X: Indicates that this to used for this part is a				east one of the hor	nogeneous materials	

China Restriction of Hazardous Substances Table

Taiwan Restriction of Hazardous Substances Table

		Restricted substances and its chemical symbols						
Unit	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr+6)	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)		
PCBs	-	0	0	0	0	0		
Metal Parts	-	0	0	0	0	0		
Plastic Parts	0	0	0	0	0	0		
Speakers	-	0	0	0	0	0		
Cables	-	0	0	0	0	0		

Note 2: The "-" indicates that the restricted substance corresponds to the exemption.

Date of Manufacture: The eighth digit in the serial number indicates the year of manufacture; "8" is 2008 or 2018.

China Importer: Bose Electronics (Shanghai) Company Limited, Part C, Plan 9, No. 353 North Riying Road, China (Shanghai) Pilot Free Trade Zone

EU Importer: Bose Products B.V., Gorslaan 60, 1441 RG Purmerend, The Netherlands

Taiwan Importer: Bose Taiwan Branch, 9F-A1, No.10, Section 3, Minsheng East Road, Taipei City 104, Taiwan Phone Number: +886-2-2514 7676

Mexico Importer: Bose de México, S. de R.L. de C.V. , Paseo de las Palmas 405-204, Lomas de Chapultepec, 11000 México, D.F. Phone Number: +5255 (5202) 3545

Apple and the Apple logo are trademarks of Apple Inc. registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android, Google Play, and the Google Play logo are trademarks of Google Inc.

The *Bluetooth*^{*} word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Bose Corporation is under license.

Bose Corporation Headquarters: 1-877-230-5639

©2018 Bose Corporation. No part of this work may be reproduced, modified, distributed or otherwise used without prior written permission.

BOSE® CONNECT APP

Features	0
----------	---

WHAT'S IN THE BOX

Contents	11
Headset components	12

IMPORTANCE OF PROPER FIT

Fit the headband	13
Choose the correct StayHear®+ tips	14
Fit the earbuds to your ear	14
Single earbud use	15
Change the StayHear®+ tips	15
Adjust the microphone	16
Conditions related to fit	17
Secure clothing clip and control module holder	17

HEADSET CONTROLS

Power on	18
Power off	18

ACOUSTIC NOISE CANCELLATION

Acoustic Noise Cancelling™ functions	19
Tap Control for talk-through communication	20
Reset Tap Control	20

OPERATION SWITCHES

Operation switch functions	21
Change the operation switches	22

MICROPHONE PLACEMENT

Yove the microphone 24	4
------------------------	---

BATTERIES

Replace the batteries

AIRCRAFT CONNECTORS

Dual plug	. 28
Connect to the aircraft	. 28
Disconnect from the aircraft	. 28
5-pin XLR, 6-pin Lemo, and 7-pin XLR	. 29
Connect to the aircraft	. 29
Disconnect from the aircraft	. 29

STATUS INDICATORS

Bluetooth indicator	30
Power indicator	31

BLUETOOTH CONNECTIONS

Connect using the <i>Bluetooth</i> menu on your mobile device	32
Connect your mobile device using the Bose® Connect app	33
Bluetooth audio priority	33
Disconnect a mobile device	34
Reconnect a mobile device	35
Recover a lost connection	35

MANAGING MULTIPLE BLUETOOTH CONNECTIONS

Connect an additional mobile device	36
Switch between connected devices	36
Clear the headset pairing list	36

BLUETOOTH FUNCTIONS

Bluetooth volume functions	37
Call functions	37

CARE AND MAINTENANCE

Store the headset	39
Clean the headset	40
imited warranty	40
Serial number location	41
Replacement parts and accessories	41
Side pad cushion	41
Headband cushion	42
StayHear®+ tips	43
Microphone windscreen	43
Batteries	43
Microphone or terminator cover	43

TROUBLESHOOTING

ry these first	4
Other solutions	4
Acoustic Noise Cancelling™ 4	4
Intercom communications 4	5
Audio	6
Microphone 4	.7
Bluetooth audio source 4	.7
Auto on/off 4	8

INSTALLATION

Mount the aircraft panel connector	49
Mono connection diagram	50
Stereo connection diagram	51
Details on making the connections	52

TECHNICAL INFORMATION

FAA Technical Standards Order 54	FAA	Technical	Standards	Order		54	1
----------------------------------	-----	-----------	-----------	-------	--	----	---

Enhance your headset experience with the Bose Connect app.

FEATURES

Easily connect to and switch between multiple mobile devices with a single swipe.

Customize your headset experience:

Name your headset.


Share audio and music.

Adjust Bluetooth volume.

Find answers to frequently asked questions.



CONTENTS



Bose® ProFlight Aviation Headset





AA batteries (2)



Control module holder






StayHear®+ tips: Large (black) and Small (white)

NOTE: Medium (gray) tips are attached to the earbuds.

NOTES: Aircraft connector types vary. See page 28.

If any part of the product is damaged, don't use it. Contact your authorized Bose® dealer or Bose customer service. Visit: global.Bose.com/Support/ProFlight


HEADSET COMPONENTS



FIT THE HEADBAND

Proper fit is important both for comfort and optimal noise cancellation performance.

1. Using the left \bigcirc and right B icons on the headband to orient the headset properly, rotate the side pads into position.



- 2. Place the headset on your head.
- 3. Adjust the headband so the side pads rest above your ears.




CHOOSE THE CORRECT STAYHEAR[®] + TIPS

For optimal audio performance, it is important to choose the correct size StayHear+ tip. Select the size that gives you the best comfort and fit in each ear. To determine the best fit, you may need to try all three sizes. You may need a different size for each ear.

NOTE: To test the fit, try speaking aloud with the headset off. Your voice should sound muffled in both ears; if not, select another tip size.


Each StayHear+ tip and earbud is marked with either an L or an R. Be sure to attach the left tip to the left earbud and the right tip to the right earbud.



FIT THE EARBUDS TO YOUR EAR

The StayHear+ tip allows the earbud to rest comfortably and securely in your ear. The tip wing fits just under your ear ridge.


- 1. Insert the earbud so the StayHear+ tip rests gently in the opening of the ear canal.
- 2. Tilt the earbud back and tuck the tip wing under the ear ridge until it is secure.



TIP: If the StayHear+ tips don't fit securely, choose a different size.

Single earbud use

When you want to use the headset with one earbud, you can stow the other earbud using the earbud storage hook on the back of the side pad.




CHANGE THE STAYHEAR[®] + TIPS

- 1. Holding the earbud, gently grasp the attached StayHear+ tip and peel it away from the earbud.
 - **CAUTION:** To prevent tearing, grasp the StayHear+ tip by its base. Do NOT pull on the tip wing.




2. Align the opening of the new StayHear+ tip with the earbud nozzle and rotate the tip onto the nozzle. Press the base of the tip until it clicks securely into place.




ADJUST THE MICROPHONE

- **NOTE:** By default, the reversible microphone ships from the factory attached to the left side of the headset. If you want to move the microphone to the other side of the headset, see "Microphone Placement" on page 24.
- 1. Grasp the microphone with your fingers, and adjust so it is level with your mouth.
 - **CAUTION:** Microphone placement is important for clear communication. It can rotate 300°. Do NOT force the microphone beyond the intended rotation or damage could occur.



2. Position the microphone so it is 0.5" (12.7 mm) from your lips, and the white surface is facing your lips.

NOTE: The microphone should not be touching your lips.



3. Test the headset before flight.

CONDITIONS RELATED TO FIT

In very loud conditions, such as during takeoff, you may experience a brief reduction in noise cancellation as the headset compensates for a momentary pressure change. If this continues when the sound level returns to normal, see "Acoustic Noise Cancellation" on page 19. If it persists, see "Troubleshooting" on page 44.


A low rumbling sound or frequent, brief losses of noise cancellation may indicate an improper fit or blocked earbud ports. See "Choose the correct StayHear®+ tips" on page 14 for information on proper fit or "Clean the headset" on page 40 for instructions on removing blockages.

During a long flight, you may feel a slight pressure point, which can be relieved by adjusting the headband position.


SECURE CLOTHING CLIP AND CONTROL MODULE HOLDER

The cable clips and control module holder enable you to secure the cable and control module to your clothing, a safety harness, sun visor rail, or aircraft headset hook for quick and easy access.

Press the side button to release and reposition the clip along the cable.




Pull the strap over the control module to secure it in place.



POWER ON

Press the Power button 🕛.



The Power indicator glows amber then blinks according to the power level. See "Power indicator" on page 31.

NOTE: The first time you power on your headset, noise cancellation is fully enabled. See "Acoustic Noise Cancellation" on page 19.

POWER OFF

Press and hold \bigcirc for three seconds then release.


When powered off, the headset provides passive audio communications.

Acoustic Noise Cancellation reduces unwanted noise providing a clearer, more lifelike audio performance. You can choose your noise cancellation based on your listening preferences and environment.

NOTE: When you receive a call, the headset remains at the current noise cancellation level.

ACOUSTIC NOISE CANCELLING™ FUNCTIONS

The Acoustic Noise Cancelling[™] switch is located on the front of the control module.



FUNCTION POSITION DESCRIPTION

High	HIGH MED LOW	Maximum quiet and noise cancellation across the entire spectrum. Best signal to noise ratio for radio and intercom communications.			
Medium HISH MED C		Optimized mode for quieter aircraft.			
Low	HIGH MED LOW	Best for interpersonal communication outside of the intercom.			


TAP CONTROL FOR TALK-THROUGH COMMUNICATION

When you need to focus on interpersonal communication coming from a specific direction, you can automatically set noise cancelling to Low on single earbud by firmly double-tapping the earbud.

NOTES: By default, Tap Control set to Off.

Tap Control is available only when the Acoustic Noise Cancelling[™] switch is in the High or Medium position.


1. Make sure the Acoustic Noise Cancelling[™] switch is in the High or Medium position.



2. Set the Tap Control switch to On. See "Change the operation switches" on page 22.



3. Firmly double-tap the earbud.



NOTE: Tap Control is not a touch control feature. You must firmly double-tap the earbud in order to activate the feature.


Reset Tap Control

To reset Tap Control and set noise cancelling in both earbuds to the Acoustic Noise Cancelling™ switch level, double-tap the earbud with Tap Control active or move the switch to another position.

OPERATION SWITCH FUNCTIONS

The operation switches are located in the control module battery compartment.

NOTE: Some operation switches are not available on all models.



FUNCTION POSITION DEFAULT DESCRIPTION

Reserved	RESERVED A - B	A	Reserved for future use.	
Auto on Auto on ON - OFF		On	Power on automatically when connected to aircraft power.	
Aircraft audio		Normal	Set sensitivity/volume of intercom audio. NOTE: Low is -12dB.	
Intercom Mono-st Mono		Mono	Process audio as mono or stereo. Available for configurations that support two-channel or stereo intercom systems only.	

	FUNCTION	POSITION	DEFAULT	DESCRIPTION		
	Auto off	on-off On auto off		Power off automatically after 3 to 45 minutes of inactivity.		
				NOTES: When running on battery power and unplugged from the intercom, the headset powers off unless there is an active mobile device audio present.		
				If you are on a call and unplugged from the intercom, the headset powers off approximately three minutes after the call is ended.		
	Tap control	ON - OFF TAP CONTROL	Off	Respond to Tap Control interaction.		

CHANGE THE OPERATION SWITCHES


- 1. Power off the headset. See page 18.
- 2. On the back of the control module, press down firmly on the finger indent and slide the cover down.

CAUTION: The battery cover is tethered to the control module. Do NOT attempt to detach it.



- 3. Remove the batteries.
- 4. Using a pen or a small, flat-tipped screwdriver, gently move the switch.


5. Insert two alkaline AA batteries, observing proper polarity.



- **CAUTION:** If the batteries don't fit correctly, do NOT force them in. Forcing an improper connection will cause permanent damage to the control module.
- 6. Close the battery cover, press firmly down on the finger indent, and slide the cover into place.




By default, the reversible microphone ships from the factory attached to the left side of the headset, however, in some configurations it may ship separately. It can be easily attached to the left or right side of the headset.




MOVE THE MICROPHONE

To move the microphone from the left side of the headset to the right side:

- 1. Locate the left ${\rm \textcircled{O}}$ and right ${\rm \textcircled{R}}$ icons on the headband to orient the headset properly.
- 2. On the left side, rotate the side pad.



3. Push the release button, and gently pull the microphone from the connector socket.



4. On the right side, push the release button, and gently pull the terminator cover from the connector socket.



5. On the left side, align the release button to the release button opening, and insert the terminator cover into the base of the connector socket.



- 6. Slide the terminator cover into the connector socket until the release button is secure.
 - **CAUTION:** Do NOT force the terminator cover into the connector socket.
 - **NOTE:** If the terminator cover is not securely installed, there will be no audio coming from that earbud.

7. On the right side, align the release button to the release button opening, and insert the microphone connector into the base of the connector socket.



8. Slide the microphone connector into the connector socket until the release button is secure.

CAUTION: Do NOT force the microphone connector into the connector socket.

9. Test the headset before flight.

REPLACE THE BATTERIES


When the battery indicator blinks red, the batteries must be replaced.

- **NOTE:** For aircraft-powered headsets, batteries are not required for operation if aircraft power is available. See "Aircraft Connectors" on page 28.
- 1. Power off the headset. See page 18.
- 2. On the back of the control module, press down firmly on the finger indent and slide the cover down.

CAUTION: The battery cover is tethered to the control module. Do NOT attempt to detach it.



- 3. Remove the batteries.
- 4. Insert two alkaline AA batteries, observing proper polarity.



- **CAUTION:** If the batteries don't fit correctly, do NOT force them in. Forcing an improper connection will cause permanent damage to the control module.
- 5. Close the battery cover, press firmly down on the finger indent, and slide the cover into place.




New alkaline AA batteries supply 45 hours of power for the headset. Battery life varies with the ambient noise level of the aircraft, temperature, ear tip condition, *Bluetooth* use, and age of the batteries. Aircraft connectors are available in several standard aircraft connector options.

POWER TYPE	CONNECTOR OPTIONS
Battery power only.	Dual plug (general aviation)
Flex Power - Aircraft power or battery power. No battery needed when connected to aircraft power. NOTE: This version is often called Flex powered and comes with an Auto On function.	5-pin XLR 6-pin Lemo 7-pin XLR NOTE: An adapter is available to convert a 6-pin Lemo connector to a Dual plug for additional connection flexibility.

NOTE: Contact Bose customer service for more information about these connectors.


DUAL PLUG

The battery (only) powered version of the headset has two general aviation aircraft connectors that insert into specific jacks on the aircraft control panel. The microphone connector is shorter, thinner and has a slightly different shape than the intercom connector.



Connect to the aircraft

- 1. Insert the thicker intercom connector into the audio jack on the aircraft control panel.
- 2. Insert the thinner microphone connector into the microphone jack on the aircraft control panel.




Disconnect from the aircraft

Gently pull back on each connector to remove the connector from the aircraft control panel.

5-PIN XLR, 6-PIN LEMO, AND 7-PIN XLR

The 5-pin XLR, 6-pin Lemo, and 7-pin XLR aircraft connectors insert into the aircraft control panel and provide the headset with aircraft power and intercom audio.



Connect to the aircraft


- 1. Align the connector to the connector keyway by matching the narrow bar on the connector to the slot on the connector.
- 2. Firmly insert the connector into the connector jack on the aircraft control panel.



Disconnect from the aircraft

5-pin XLR and 7-pin XLR

- 1. Press the button/latch on the aircraft control panel to release the connector, if necessary.
- 2. Gently pull back to remove the connector from the aircraft control panel.



6-pin Lemo

1. Pull back on the sleeve near the end of the connector.


CAUTION: You must pull back on the sleeve before you pull out the connector. Forcing the connector out will damage the cable and/or the aircraft control panel.

2. Continue gently pulling back to remove the connector from the aircraft control panel.

The Bluetooth and Power indicators are located on the front of the control module.

BLUETOOTH INDICATOR

Shows the connection status of a mobile device.




	SYSTEM STATE
Blinking purple (in sync with Power indicator)	Ready to connect
Blinking blue (alternating with Power indicator)	Connecting
Blinking blue (in sync with Power indicator)	Connected

NOTE: To dim the *Bluetooth* and Power indicators, double-press \bigcirc .

POWER INDICATOR

Shows the power source and level.



POWER SOURCE	INDICATOR ACTIVITY	SYSTEM STATE
Aircraft	Slow blinking green	Power On
Battery	Blinking green	Power On—batteries high (8 hours or more)
Battery	Blinking amber	Power On—batteries low (2 to 8 hours remaining)
	Blinking red	Power On—batteries low (2 hours or less remaining)
Battery		NOTE: When the batteries reach this level, the <i>Bluetooth</i> feature is disabled to conserve remaining power. You hear a tone, indicating that your <i>Bluetooth</i> device is being disconnected and the <i>Bluetooth</i> feature is turning off.
Aircraft or battery	None	Power Off or batteries depleted

NOTE: To dim the Power and *Bluetooth* indicators, double-press \bigcirc .

New alkaline AA batteries supply 45 hours of power for the headset. Battery life varies with the ambient noise level of the aircraft, temperature, ear tip condition, *Bluetooth* use, and age of the batteries.

Bluetooth wireless technology lets you stream audio from mobile devices such as smartphones, tablets, and laptop computers. Before you can stream audio from a device, you must connect the device with your headset.

CONNECT USING THE *BLUETOOTH* MENU ON YOUR MOBILE DEVICE

1. Make sure the *Bluetooth* priority switch is in the Mute or Mix position. See "Change the operation switches" on page 22.

NOTE: If the *Bluetooth* priority switch is set to Off, *Bluetooth* is disabled.

2. Press and hold the *Bluetooth*/Multi-function button \$ for one second.

The *Bluetooth* indicator blinks purple.

3. On your mobile device, enable the *Bluetooth* feature.

TIP: The *Bluetooth* feature is usually found in the Settings menu.

4. Select the headset from the device list.



Once connected you hear a tone, and the *Bluetooth* indicator blinks blue.

NOTES: After five minutes of inactivity, the headset automatically exits pairing mode, and the *Bluetooth* indicator turns off. To turn the *Bluetooth* feature back on, press .

Each time you turn on the *Bluetooth* feature, the headset attempts to reconnect with the two most recently connected *Bluetooth* devices. If the device(s) are turned off or out of range, the headset returns to pairing mode after five minutes. See "Reconnect a mobile device" on page 35.

CONNECT YOUR MOBILE DEVICE USING THE BOSE[®] CONNECT APP

Download the Bose Connect app, and follow the on-screen connections instructions.




Once connected you hear a tone, and the *Bluetooth* indicator blinks blue.

BLUETOOTH AUDIO PRIORITY

The aircraft intercom system (ICS) is always the headset's primary audio source. When the headset is plugged in to the aircraft, intercom signals are always heard and cannot be muted by the headset. You can configure how you hear the device audio with the intercom.

NOTE: *Bluetooth* audio will never override the intercom.

The *Bluetooth* priority switch is located on the front of the control module.



FUNCTION	POSITION	DESCRIPTION	
Mute	MUTE MIX OFF	When an intercom signal is detected, <i>Bluetooth</i> audio is temporarily muted until intercom audio ceases.	
Mix	MUTE MIX OFF	When an intercom signal is detected, <i>Bluetooth</i> audio is mixed with intercom audio. You hear a maximum of two audio sources; the intercom plus one <i>Bluetooth</i> device.	
MUTE MX OFF		Only intercom audio is active. <i>Bluetooth</i> functionality is disabled.	
	OFF	NOTES: All <i>Bluetooth</i> connections are disabled and antennae power is removed.	
		If you switch to OFF while connected to a <i>Bluetooth</i> device, you may need to re-establish your <i>Bluetooth</i> connection the next time you turn on the headset.	

NOTES: When Mute or Mix are selected, incoming and outgoing phone calls automatically mute all other secondary audio sources.

During a phone call, the intercom and the phone call are heard as mixed.

DISCONNECT A MOBILE DEVICE

Press and hold the *Bluetooth*/Multi-function button \$ for 5 seconds to turn the *Bluetooth* feature off.

Move the *Bluetooth* priority switch to the Off position.

Use the Bose® Connect app to disconnect your mobile device.

TIP: You can also use *Bluetooth* settings to disconnect your device. Disabling the *Bluetooth* feature disconnects all other devices.

RECONNECT A MOBILE DEVICE

When powered on, the headset tries to reconnect with the two most recently-connected devices.

NOTE: The devices must be within range (30 ft. or 9 m) and powered on.

RECOVER A LOST CONNECTION

When your connected mobile device moves out of range, the connection is lost. The headset automatically attempts to reconnect. If the headset is unable to reconnect, it returns to pairing mode. After five minutes of inactivity, the *Bluetooth* feature turns off.

- 1. Move the device back into range.
- 2. Press the *Bluetooth*/Multifunction button \$ to reconnect.

You can pair additional devices to your headset. These *Bluetooth* connections are controlled with the *Bluetooth*/Multi-function button &. Before connecting an additional mobile device, make sure this feature is enabled.

TIP: You can also easily manage multiple connected devices using the Bose® Connect app.

CONNECT AN ADDITIONAL MOBILE DEVICE

You can store up to eight paired devices in the headset pairing list, and your headset can be actively connected to two devices at a time.

To connect an additional device, use the *Bluetooth* menu on your device or download the Bose Connect app.

NOTES: Only one device can be heard at a time.

Bluetooth audio will never override the intercom.

SWITCH BETWEEN CONNECTED DEVICES

- 1. Pause audio on your first device.
- 2. Play audio on your second device.


CLEAR THE HEADSET PAIRING LIST

- 1. Press and hold *≹* and simultaneously for seven seconds, or until the *Bluetooth* indicator blinks purple in sync with the Power indicator.
- 2. Delete the headset from the *Bluetooth* list on your device.

All devices are cleared, and the headset is ready to connect. See "*Bluetooth* Connections" on page 32.

BLUETOOTH VOLUME FUNCTIONS


The *Bluetooth* volume controls are located on the side of the control module.



FUNCTION	WHAT TO DO
Bluetooth volume	Press +.
Bluetooth volume down	Press —.

CALL FUNCTIONS

The *Bluetooth*/Multi-function button *𝔅* is located on the front of the control module.



FUNCTION	WHAT TO DO	
Make a call	Dial from your connected phone. The call automatically transfers to the headset.	
Answer a call	Press ∦ . You hear a short beep before you hear the incoming call.	
End a call	Press ∦ . You hear two short beeps indicating the call has ended.	
Decline an incoming call	Press and hold ∦ for one second. You hear two short beeps indicating the call has been declined.	

FUNCTION	WHAT TO DO	
Answer a second incoming call and put the current call on hold	While on a call, press the <i>Bluetooth</i> /Multi-function button <i>§</i> . You hear a short beep before you hear the second call.	
Decline a second incoming call and stay on current call	While on a call, press and hold * for one second. You hear two short beeps indicating the call has been declined.	
Switch between two calls	With two active calls, double-press ∦. You hear a short beep before you hear the incoming call.	
Redial the last number	When there are no active or incoming calls, double-press \$.	
Transfer audio to the mobile device	While on a call, press and hold $\$$ for three to four seconds. The audio is transfered to the mobile phone while the <i>Bluetooth</i> connection remains active.	
Activate voice control	When there are no active or incoming calls, press *.	
Mute/unmute a call	While on a call, press + and — simultaneously. You hear two short beeps indicating the call has been muted/unmuted.	

NOTES: If you are on a call and unplugged from the intercom, the headset powers off approximately three minutes after the call is ended.

To use the headset when unplugged from the intercom (to listen to audio or to make or receive calls), Bose recommends to disable the Auto Off feature for uninterrupted functionality. See "Operation Switches" on page 21.


Some functions may not be available for some mobile devices. Refer to your device owner's guide for more information.

STORE THE HEADSET

Place the headset in the carry case for easy, convenient storage.

Store the headset in a ventilated area away from direct sunlight.

Remove the batteries before storing the headset for extended periods.



- 1. Rotate the microphone up to the headband.
- 2. Adjust the headband.
- 3. Rotate the side pads.
- 4. Place the headband in the case, making sure it rests securely on the moldings.
- 5. Wrap the control module cable around the perimeter of the case.
- 6. Place the control module in the center of the headband.
- 7. Wrap the remaining cable around the perimeter of the case.

CLEAN THE HEADSET

Your headset may require periodic cleaning.

COMPONENT	CLEANING PROCEDURE		
Headset	Wipe the outside surfaces of the headband, headband cushion, side pads, connectors, and plastic parts using a soft, damp cloth (water only) and mild soap. CAUTION: Do NOT immerse the headset in water or any liquid.		
StayHear'+ tips	 Remove the StayHear*+ tips from the earbuds and wash them with a mild soap and water. Once the StayHear+ tips are completely dry, re-attach them to the earbuds. 		
Microphone windscreen	 Gently slide or roll the windscreen off the microphone. Rinse and dry the windscreen. Once the windscreen is completely dry, slide the windscreen back on the microphone. Make sure it fits completely over the microphone. 		

LIMITED WARRANTY


The headset is covered by a limited warranty. Details of the limited warranty are provided on the product registration card that is in the carton. Please refer to the card for instructions on how to register. Failure to do so will not affect your limited warranty rights.

The warranty information provided with this product does not apply in Australia and New Zealand. See our website at www.bose.com.au/warranty or www.bose.co.nz/warranty for details of the Australia and New Zealand warranty.

- 1. Contact the Bose organization in your country/region (visit www.global.Bose.com for Bose contact information in your country/region) for specific return and shipping instructions.
- 2. Label and ship the product, freight prepaid, to the address provided by the Bose organization in your country.
- 3. Place any necessary return authorization number prominently on the outside of the carton. Cartons not bearing a return authorization number, where required, will be refused.

SERIAL NUMBER LOCATION

The serial number is located on the side pad. To view the serial number, gently grab and peel the side pad cushion from the left edge away from the side pad.



Reference this serial number when you register your product or contact Bose for technical support.

REPLACEMENT PARTS AND ACCESSORIES

Through normal use, parts like windscreens and ear tips may require periodic replacement. Replacement parts and accessories can be ordered through Bose customer service. Visit: global.Bose.com/Support/ProFlight

Side pad cushion

1. Gently grab and peel the side pad cushion away from the side pad.



2. Align the new side pad cushion to the side pad.




3. Press the Velcro to secure the side pad cushion in place.

Headband cushion


Replace the cushion after regular care and maintenance fails to restore the cushion to its original size and shape.

1. Gently grab and peel the headband cushion away from the headband.



2. Place the new headband cushion under the headband with adhesive facing rear.







3. Fold the adhesive flap over the headband.



4. Peel away the adhesive backing, fold top flap, and adhere the top to the adhesive.



5. Insert the left and right tabs into the plastic cap.



StayHear®+ tips

Replace tips every six months or every 350 hours of use, depending on how often you fly. See "Change the StayHear®+ tips" on page 15. You may have to replace them more often, if you:

Subject the headset to severe temperature extremes such as parking your airplane outside in severe cold or heat.

Put excess strain on the tips because of improper storage.

To extend the life of the StayHear+ tips, clean them regularly. See "Clean the headset" on page 40.

Microphone windscreen

- 1. Gently slide or roll the windscreen off the microphone.
- 2. Slide the replacement windscreen on the microphone.
- 3. Make sure it fits completely over the microphone.

Batteries

See "Batteries" on page 27.

Microphone or terminator cover

See "Microphone Placement" on page 24.

TRY THESE FIRST

If you experience problems with your headset, try these solutions first:

Power on the headset (see page 18).

Check the state of the status indicators (see page 30).

Make sure the earbud is fully inserted and securely sealed (see page 14).

Make sure your mobile device supports *Bluetooth* (see page 32) 2.1 and greater.

Increase the volume on your *Bluetooth* device (see page 37) and audio or music app.

Try connecting another *Bluetooth* device (see page 36).

OTHER SOLUTIONS

If you could not resolve your issue, see the table below to identify symptoms and solutions to common problems. If you are unable to resolve your issue, contact Bose customer service.

Visit: global.Bose.com/Support/ProFlight

Acoustic Noise Cancelling[™]

PROBLEM	WHAT TO DO		
Communication, but no noise cancellation in either ear	If using aircraft power, check the aircraft fuse or circuit breaker. If using battery power, make sure the batteries are fresh and correctly		
	 installed. See "Batteries" on page 27. If using aircraft power, make sure the connector is firmly seated in the control panel and the control panel has power. See "Aircraft Connectors" on page 28. Power off, then power on the headset. See "Headset Controls" on page 18. NOTE: Do not press the Power button () repeatedly. 		
No active noise cancellation and no communication	If using battery power, make sure the batteries are fresh and correctly installed. See "Batteries" on page 27. If using aircraft power, make sure the connector is firmly seated in the control panel and the control panel has power. See "Aircraft Connectors" on page 28. Power off, then power on the headset. See "Headset Controls" on page 18. NOTE: Do not press the Power button () repeatedly. Use the headset in a different seat location. Remove microphone assembly from the headset, and check for damage to the connector or pins. See "Move the microphone" on page 24.		

Intercom communications

PROBLEM	WHAT TO DO		
Noise cancellation active, but no incoming audio	Make sure the volume controls are not set too low on the control module (see page 37) or the intercom. Make sure the aircraft connectors are securely inserted into the aircraft control panel. See "Aircraft Connectors" on page 28.		
	Use a different seat location in the aircraft.		
	Make sure the volume controls are not set too low on the control module (see page 37) or the intercom.		
Low volume	Make sure the Intercom operation switch is correctly set for your intercom system. See "Operation Switches" on page 21.		
of incoming communications	Make sure all headsets sharing the intercom have the Intercom operation switch in the correct position. See "Operation Switches" on page 21.		
	Unplug all other headsets and see if the volume can be adjusted to an acceptable level.		
Intermittent	Make sure the aircraft connectors are securely inserted into the aircraft control panel. See "Aircraft Connectors" on page 28.		
communication	Use a different seat location in the aircraft.		
Reduced volume in one ear only	Make sure the volume controls are not set too low on the control module (see page 37) or the intercom.		
	Make sure the Intercom operation switch is correctly set for your intercom system. See "Operation Switches" on page 21.		
	Make sure the Intercom operation switch is correctly set for your intercom system. See "Operation Switches" on page 21.		
No stereo separation or	Make sure the terminator cover is securely installed. See "Move the microphone" on page 24.		
communications in one ear only	Depending on how your audio jacks are wired, there may be only one channel of audio supplied to the headphone jack. If the Intercom (MON-ST) operation switch is set to ST and you only hear communications on one side, set the operation switch to MON to play audio on both sides. 5-pin XLR models are mono audio only.		

Audio

PROBLEM	WHAT TO DO		
Reduced noise cancellation, intermittent clicking sounds, or communication distortion in a loud environment	Make sure the StayHear®+ tips are clean and free of debris. See "Clean the headset" on page 40.		
	If the headset emits any loud noise and related loss of communications while in the Acoustic Noise Cancelling™ mode, turn the power off. The headset will continue to provide communications in the passive noise reducing mode.		
	Make sure the headset orientation is correct. Use the Left () and Right () markings on the headset to orient the headset correctly.		
Squealing or	Make sure the StayHear+ tips are firmly seated on the earbuds.		
whistling sound when the headset powers on	Make sure the earbuds are fully seated in your ears. See "Fit the earbuds to your ear" on page 14.		
	Make sure the proper sized StayHear+ tips are being used. See "Choose the correct StayHear®+ tips" on page 14.		
	Make sure the earbud openings are clean and free of debris.		
Low rumbling sound with the headset turned on in a quiet environment	Make sure the earbuds fit correctly. See "Choose the correct StayHear®+ tips" on page 14.		
	Make sure the StayHear+ tips are clean and free of debris. See "Clean the headset" on page 40.		
	Make sure the headset orientation is correct. Use the Left () and Right () markings on the earbuds to orient the headset correctly.		
Crackling sound audible with headset	Make sure the earbuds fit correctly. See "Choose the correct StayHear®+ tips" on page 14.		
turned on in a loud environment, or noise cancelling is intermittent	Make sure the StayHear+ tips are clean and free of debris. See "Clean the headset" on page 40.		
	If using battery power, check if the battery is low. See "Power indicator" on page 31.		
	If using aircraft powered, make sure the voltage powering the headset is no less than 10 VDC.		

WARNING: If the headset emits any loud noise and related loss of communications while in the Acoustic Noise Cancelling[™] mode, turn the power off. The headset will continue to provide communications in the passive noise reducing mode.

Microphone

PROBLEM	WHAT TO DO		
No sound to the microphone	Make sure the white surface on the microphone is facing your lips. See "Adjust the microphone" on page 16.		
	Make sure the microphone is fully connected to the headband. See "Microphone Placement" on page 24.		
	Check the Squelch level on the intercom. The Squelch level may need to be adjusted.		
	Try another intercom position in the aircraft.		
	For <i>Bluetooth</i> phone calls, make sure the batteries are fresh and correctly installed. See "Batteries" on page 27.		

Bluetooth audio source

PROBLEM	WHAT TO DO		
No audio from the <i>Bluetooth</i> source to the headset while on a call	Make sure the intercom operation switch is in the Mute or Mix position. Turn on and off <i>Bluetooth</i> on the mobile device. Make sure the <i>Bluetooth</i> feature is on, and the <i>Bluetooth</i> indicator is flashing. See " <i>Bluetooth</i> Connections" on page 32. Make sure the headset and device are in range (30 ft. or 9 m). Make sure the mobile device is connected properly and the headset is ready to pair. See " <i>Bluetooth</i> Connections" on page 32.		
	Make sure the <i>Bluetooth</i> volume is not set too low on the control module. See " <i>Bluetooth</i> volume functions" on page 37.		
Headset does not pair with a device	Turn on and off <i>Bluetooth</i> on the mobile device.		
	Make sure the <i>Bluetooth</i> feature is on, and the <i>Bluetooth</i> indicator is flashing. See " <i>Bluetooth</i> Connections" on page 32.		
	Make sure the <i>Bluetooth</i> priority switch is in the Mute or Mix position. See " <i>Bluetooth</i> audio priority" on page 33.		
	Clear the headset pairing list (see page 36) and connect again.		
	Delete the headset from your device's <i>Bluetooth</i> device list and pair again.		
Cannot answer/end a call	Make sure your device is connected to the headset.		

PROBLEM	WHAT TO DO		
Headset does not reconnect to a previously connected device	Make sure the headset and device are in range (30 ft. or 9 m). Make sure the <i>Bluetooth</i> priority switch is in the Mute or Mix position. See " <i>Bluetooth</i> audio priority" on page 33. Make sure the <i>Bluetooth</i> feature is on, and the <i>Bluetooth</i> indicator is flashing. See " <i>Bluetooth</i> Connections" on page 32. On your mobile device, make sure the <i>Bluetooth</i> feature is on. Delete the headset from your device's <i>Bluetooth</i> device list and pair again.		

Auto on/off

NOTE: This function is not available for Dual plug connectors.

PROBLEM	WHAT TO DO		
Headset does not power on automatically	Make sure the Auto on operation switch is set to ON. See "Operation Switches" on page 21.		
	Check the aircraft specifications to see if the jack is getting power from the aircraft's electrical system.		
Headset does not power off automatically	Make sure the Auto off operation switch is set to ON. See "Operation Switches" on page 21.		
	Disconnect the headset from the aircraft. Then power on the headset and wait 15 minutes.		
	It may take up to 9 minutes for the headset to power off when not in use immediately after initial power up. If the headset has not powered off after 15 minutes, contact Bose technical support.		

MOUNT THE AIRCRAFT PANEL CONNECTOR


The aircraft panel connector is part of the optional 6-pin wiring harness assembly.




Visit www.Bose.com or www.global.Bose.com for information or purchase.

WARNING: The aircraft panel connector must be mounted by a technician who is qualified to perform this type of avionics installation for the aircraft you are using.


Mount the connector into a cutout, using the diagrams below as a guide.



Receptacle - Pinout (front view)



Aircraft Interface Schematic



Connect the eight wires as follows:

Two for the microphone

Two for audio

One for power


One for ground


Two for audio shields

Audio and microphone wires should be connected to the back of the existing microphone and headphone jacks, leaving existing jacks intact for use with conventional headsets. This is usually the fastest installation method.

- **CAUTION:** Do NOT use excessive force or bend the installed connector. This may damage or break internal solder joints.
- **NOTE:** The aircraft panel connector cannot be installed in an audio system using transformer-coupled audio outputs. Contact Bose technical support.

Mono connection diagram





Stereo connection diagram

Details on making the connections

The pinouts for the optional installed connector are detailed in the table below.

PIN NUMBER	COLOR	PURPOSE
1	Red	V+IN: Headset power (10-32 VDC). Use a 1/4 amp fuse or a 1/2 amp circuit breaker.
2	Black	GND: System ground. Connect to the existing audio ground.
3	White	COMM L: Phone communication: Left.
4	Blue	COMM R: Phone communication: Right.
NOTE: For stereo operation, connect the left and right channels to their respective positions. For monaural operation, connect pins 3 and 4 together, and to the tip of the existing phone jack.		
5	White	MIC HI: Microphone/Hi-audio. Connect to the portion of the existing microphone jack that corresponds to the ring position of a headset microphone plug. Do not connect to the tip (PTT) segment.
6	White/Blue	MIC LO: Microphone/Lo-ground. Connect to the portion of the microphone jack that corresponds to the barrel position of a headset microphone plug.
NOTE: If the microphone works on radio transmit but not through the intercom, check pin 6. It may be incorrectly wired to the PTT segment of the microphone jack.		
Comm Shield	Black	Shield from Comm L and Comm R wire pair.
Mic Shield	Black	Shield from Mic Hi and Mic Lo wire pair.
NOTE: The wires connecting pins 3 and 4 and pins 5 and 6 are shielded, twisted pairs with a black wire shield termination exiting each pair. If the existing wiring is not shielded, connect the shields to the existing audio wiring shields, or connect the shield from Comm L and Comm R wire pair to audio ground.		

SPECIFICATION	DESCRIPTION	
Headphone sensitivity	92dB SPL measure at 1 mW input signal, 1 kHz, in Mono mode	
Headphone impedance	Mono mode: 300 Ohms ON and OFF Stereo mode: 600 Ohms ON and OFF	
Headphone frequency response	RTCA-214a range: 300 to 3500Hz Extended range: 40Hz to 15kHz	
Boom microphone sensitivity	-27dBV (+/- 2.5dB) at 94dB SPL (1 Pa), measured at 6mm distance from artificial mouth, across 220 Ohms load resistor and biased with 12 Vdc via 470 Ohms resistor.	
Boom microphone bias	Operating bias voltage range: 4 to 28 VDC.	
Maximum ambient noise level	105 dBC SPL for full active noise reduction performance	
Battery power source	Two (2) AA alkaline batteries	
Battery life	45 hours in typical commercial jet aircraft noise. Duration varies with battery age, ambient noise levels, temperature, ear tip condition, and use of the <i>Bluetooth</i> feature.	
Aircraft power source	Aircraft power voltage range: 10 to 32 VDC	
Average power consumption	250mW	
Fuse/breaker recommended	1/4 amp, fast-blow fuse (AGC 1/4 amp fuse) or 1/2 amp circuit breaker	
Headset weight	4.9 ounces	
Headset size range	Slider not extended: 8.425" (214mm) H x 6.34" (161mm) W x 3.15" (80mm) D Slider extended: 10.2" (259mm) H x 6.6" (168mm) W x 3.15" (80mm) D	
Control module dimensions	1.5" (38.1mm) H x 1.5" (38.1mm) W x 4.92" (125mm) D	

SPECIFICATION	DESCRIPTION
Temperature and Altitude (Category A)	Operating: 5 to 158°F (-15 to 70°C) Storage: -67 to 158°F (-55 to 70°C) Altitude: 15,000 feet maximum pressure altitude for full cancellation
<i>Bluetooth</i> wireless technology	4.1

FAA TECHNICAL STANDARDS ORDER

The Bose® ProFlight Aviation Headset that is approved to TSO and ETSO C139a are appropriately marked. The product interface, cables, and microphones have been designed to function in or withstand exposure to the environmental conditions below.

CONDITION	CATEGORY
Altitude and temperature	A2
Salt fog	S
AF conducted susceptibility	В
Humidity	A
Magnetic effect	Z
Power input	В
RF Susceptibility	T and R
Vibration	S and R
Voltage spike	В
Shock drop	12 times, 1 m onto concrete (per DO-214a)
Explosive atmosphere	Х
Electrostatic discharge	A

Environmental categories cited refer to RTCA/DO-160G and RTCA/DO-214a (December 18, 2013).

The conditions and tests required for TSO approval of this are minimum performance standards. It is the responsibility of those installing this article either on or within a specific type or class of aircraft to determine that the aircraft installation conditions are within the TSO standards. TSO articles must have separate approval for installation in aircraft. The article may be installed only if performed under 14 CFR part 43 or the applicable airworthiness requirements.

This device complies with FCC and Industry Canada RF radiation exposure limits for general population. It must not be collocated or operating in conjunction with any other antenna or transmitter.





©2018 Bose Corporation, The Mountain, Framingham, MA 01701-9168 USA AM802347 Rev. 01